

Technical Bulletin IG 5.1

EnerEDGE[®] Desiccant Test Kit and Instructions



STEP 1 – Use an approved vial available from Tremco or other approved suppliers. Kimble Chase 60965D-7 with closure.



STEP 2 – Use an approved humidity indicator card available from Tremco. Expose the card to ambient air until round spot turns pink. These cards are reusable.



STEP 3 – Place the humidity indicator card into the vial with the indicator side facing out. This allows the result to be easily read.



STEP 4 – Without removing the liner, cut enough pieces of EnerEDGE[®] approx. 1/8" to 3/16" long to fill the vial.



STEP 5 – Fill the vial to the top with pieces of EnerEDGE[®]. Place the cap on securely.



STEP 6 – If the round spot turns blue, typically within 1 hour, the spacer is usable.



STEP 7 – If after 1 hour, the indicator remains pink, repeat the test with fresh spacer taken 2 layers underneath the original spacer. If this fails, contact your Tremco representative.

