

## Sloped Glazing



- Consideration must be given to the weight of the glass or panel on the interior gasket and its ability to properly support this weight.
- Non-shim tapes and sponge gaskets should not be used on the interior because the dead load of the glass panel may over-compress the glazing material.
- Special design considerations must be given to the exterior framing system is used, so as not to allow water to pond on gaskets or sealants.
- System design must accommodate drainage of condensation and water infiltration.



- Cruciforms and custom extrusions can be installed to restore areas where water can enter the system.



For more information on Tremco's Glazing and Facade Restoration Solutions, please visit our website at [www.tremcosealants.com](http://www.tremcosealants.com) or contact your local Tremco Sales Representative.