



Apply ExoAir Primer to the surface of the ExoAir 110 prior to applying the membrane. The membrane should overlap the ExoAir 110 by a minimum of 2"

This detail is intended for conceptual purposes only.

Rev	Date	Description	By
-	-	-	-