



ExoAir 120

ExoAir TWF, recessed
1/2" from exterior

Metal drip edge

Spectrem 1 sealant

Paraterm Bar with
Dymonic 100 or
Vulkem 116
Note: Vulkem 116
must be fully cured
prior to installing
ExoAir TWF

TREMdrain

Paraseal

Dymonic 100 or
ExoAir Termination
Mastic

ExoAir TWF with
ExoAir Primer

4" Min.

Dymonic 100,
Dymeric 240FC or
Tremflex 834

Paraterm Bar with
Vulkem 116 (fully
cured) or
Dymonic 100

ExoAir TWF

ExoAir Primer

TREMdrain

Paraseal

Note: Paraseal products require a minimum 24 psf compaction/ confinement in order to function as designed

This detail is intended for conceptual purposes only. Detail must be reviewed by a project/design professional. See www.tremcosealants.com for the most up-to-date product information.

Rev	Date	Description	By
-	-	-	-