



ExoAir 220/230
Apply ExoAir Primer
to the surface of the
ExoAir 110 prior to
applying
membrane. The membrane should
overlap the ExoAir 110 by a min 2"

Note: This sample detail is for educational purposes only. Appropriate air barrier details vary by geographic location, climatic conditions, air barrier products used in actual design, and anticipated building use. Contact Tremco Technical Services for further assistance.

Drawing Number

A10071

Date: 08/19/10

Detail

Window Sill - Exterior Sheathing-3

Drawn by: K. Thorpe

Scale: None

3735 Green Road * Beachwood, OH 44122
Phone : 866-209-2404 * Fax: 216-766-5535

TREMCO
www.tremcoairbarriers.com