



Fold Paraseal LG Back On Itself To Protect Bentonite Side. Then, Unfold and Nail To Backfilled Wall Every 24" o.c.

Permanent Tape and 24" o.c. Nailing At All Backfilled Seams.

Paraseal LG with HDPE Side Facing Installer.

Backfilled Wall of Different or Like Material.

Paraseal LG Installation at Blindside to Backfilled Transition - Plan View.

No.	Date	Description	By

Project:
TREMCO
 3735 Green Road
 Beachwood, Ohio 44122 216-292-5000

Blindside Walls

Drawn by: A. Murph	Scale: Not To Scale	Date: 4-9-08	Drawing/Index No. BSW-22
-----------------------	------------------------	-----------------	-----------------------------