



**Note:** Vulkem 950NF may be used as topcoat in areas with no U.V.

**Note:** There are several techniques for installation around drains. You may also take the membrane down into the drain assembly. The drain assembly must be blocked if this application is preferred. The metal or plastic drain should be scuffed and cleaned and primed with Tremco's TREMprime Nonporous Primer.

Detail	Deck Coating Drain System	Drawing Number	DC-32
	Drawn by: K. Thorpe	Scale: None	Date: 07/12/10
<p>3735 Green Road * Beachwood, OH 44122          Phone : 866-209-2404 * Fax: 216-766-5535</p> <p><b>TREMCO</b><sup>®</sup>          www.tremcosealants.com</p>			