



Treatment of Cracks Less than 1/16"

Note:
 Tremprime QD or another Tremco approved primer must be applied before the application of TREMproof 6100