



Note:
 Tremprime QD or another Tremco approved primer must be applied before the application of TREMproof 6100

Treatment of Parapet or Column