



Treatment of Parapet or Column

Note:
Tremprime QD or another Tremco approved primer must be applied before the application of TREMPROOF 6100