



Typical Tremco Hot Applied Membrane w/ Pavers & Insulation

Note:
 Tremprime QD or another Tremco approved primer must be applied before the application of TREMproof 6100