



Note:
Tremprime QD or another Tremco approved primer must be applied before the application of TREMproof 6100

Planter Box Detail