



Parapet Cap Splice Application

1. Apply adhesive/sealant to parapet cap as usual
2. Install preformed joint sealant allowing for adequate drip edge

TREMCO

www.tremcosealants.com

3735 Green Road * Beachwood, OH 44122
 Phone : 866-209-2404 * Fax: 216-766-5535

Project:
 Detail: Spectrem Simple Seal - Parapet Cap Splice Application

This detail is intended for conceptual purposes only.

Drawn by: SD

Checked by:

Scale: None

Sheet Number:

Date: 10/26/2016

File Name:

Rev #

00