

Single Component Elastomeric Adhesive

### CMU / Cinder Block

All surfaces should be clean and free of contaminants before application.

### Application

#### MEDIUM STONE

- Apply TREMGrip® along the stone.
- Place the second stone onto the bead of TREMGrip, applying pressure until adhered (approximately 20 seconds).

#### LARGE STONE

- Apply TREMGrip along the stone, leaving 1.5" between beads.
- Place the second stone onto the beads of TREMGrip, applying pressure until adhered (approximately 30 seconds).

#### CINDER BLOCK

- Apply TREMGrip along the block, leaving 1.5" between beads.
- Place the second block onto the beads of TREMGrip, applying pressure until adhered (approximately 35 seconds).



### Block Sizes and Weights

	Weight	Size
<b>Medium</b>	2 LBS weighed together	4 x 8, 1" thick
<b>Large</b>	4.4 LBS weighed together	14 x 2.4, 1.5" thick
<b>Cinder Blocks</b>	14 LBS weighed together	7 1/2 x 7 3/4, 3/12" thick



SEE TREMGrip IN ACTION AT:  
<https://www.youtube.com/watch?v=LXmZtBDKqRM>