



Parastick N Dry (or Superstop) wrapped around pipe and adhered to itself. Use Paraprimer. Tie-wire may also be installed to help hold in place.

2" x 1" (50mm x 25mm) Paragranular or paramastic cant around pipe

Paraseal LG; bentonite side facing installer

Paraseal "washer" slipped over pipe; bentonite side facing installer

Compacted earth or granular base min. 85 proctor

Pipe, elevator cylinder or other

Note: Paraseal products require a minimum 24 psf compaction/ confinement to be effective.

This detail is intended for conceptual purposes only. Detail must be reviewed by a project/design professional. See www.tremcosealants.com for the most up-to-date product information.

Rev	Date	Description	By
1	10/10/2013	Update Detail	KAB



www.tremcosealants.com
3735 Green Road * Beachwood, OH 44122
Phone : 866-209-2404 * Fax: 216-766-5535

Project: Below Slab-on-Grade
Detail: Thru Floor Penetration (Cast-In-Place)

Drawn by: KT Checked by: WH

Sheet Number:
Date: 8/26/2009

File Name:
10864

Rev #
1