



Notes: Paraseal products require a min 24 PSF of compaction/confinement in order to function as designed.

ExoAir Primer must be used with ExoAir TWF

**TREMCO**

www.tremcosealants.com

3735 Green Road \* Beachwood, OH 44122  
Phone : 866-209-2404 \* Fax: 216-766-5535

Project:

Detail: Impermeable Fluid Transition to Paraseal

Sheet Number:

File Name:

AVB-CI-F-T-01

This detail is intended for conceptual purposes only.

Drawn by: KAB

Checked by: MAT

Scale: None

Date: 12/21/2018