



Notes: ExoAir Primer must be used with ExoAir 110 and ExoAir TWF



www.tremcosealants.com  
 3735 Green Road \* Beachwood, OH 44122  
 Phone : 866-209-2404 \* Fax: 216-766-5535

Project:

Detail: Impermeable Sheet Transition to TREMproof 250GC

Sheet Number:

File Name:

AVB-CI-S-T-03

This detail is intended for conceptual purposes only.

Drawn by: KAB

Checked by: MAT

Scale: None

Date: 12/21/2018