

ExoAir 120

tremcocpg.com

Tremco Technical Support: 866-209-2404

Detail: Impermeable Fluid Transition to Paraseal Drawn by: KAB Checked by: CB

Scale: NTS

Date: 4/25/2023

AVB-SI-F-T-01

File Name:

