



Note: Paraseal products require a min 24 PSF of compaction/confinement in order to function as designed.

TREMCO <small>www.tremcosealants.com</small> <small>3735 Green Road * Beachwood, OH 44122</small> <small>Phone : 866-209-2404 * Fax: 216-766-5535</small>	Detail: TREMproof 260 to Paraseal at Base of Wall			Sheet Number:	File Name: C-260-T-01
	This detail is intended for conceptual purposes only.	Drawn by: KAB	Checked by: WH	Scale: None	Date: 7/25/2018