



Note: TREMprime QD or Tremco approved primer must be applied before the application of TREMproof 6100

TREMCO
 www.tremcosealants.com
 3735 Green Road * Beachwood, OH 44122
 Phone : 866-209-2404 * Fax: 216-766-5535

Project:
 Detail: TREMproof 6100 at Upturn with Elastomeric Sheeting

This detail is intended for conceptual purposes only.

Drawn by: KAB

Checked by: WH

Scale: None

Sheet Number:

Date: 8/1/2018

File Name:
 H-U-01