



- NOTE: Sand slurry protection slab is recommended for reinforced slabs greater than 12" thick.
- NOTE: Parastick N Dry may be adhered with Paraprimer and placed over the seam (as shown) or placed inside the open edge of the seam prior to fastening the seam.
- NOTE: Paraseal products require a min of 24 PSF of compaction/confinement in order to function as designed.
- NOTE: Not for use in submerged conditions.
- NOTE: Refer to detail TWS-BSOG-05
- NOTE: If Mud Slab is not placed refrain from using chipped aggregate.

TREMCO

www.tremcosealants.com

3735 Green Road * Beachwood, OH 44122
 Phone : 866-209-2404 * Fax: 216-766-5535

Detail: TREMproof TWS - BELOW SLAB ON GRADE
 (BENTONITE SIDE UP) - (NON-SUBMERGED)

This detail is intended for conceptual purposes only.

Drawn by: MI

Checked by: AC

Scale: None

Sheet Number:

Date: 5/27/2016

File Name:

TWS-BSOG-02

Rev #

00