



WHEN SPRAYING SHOTCRETE OR OTHER MATERIALS AGAINST PARASEAL GM/LG, SPRAY EITHER DIRECTLY AT THE SEAM OR AT THE CLOSED EDGE OF THE SEAM SO AS NOT TO LODGE SPRAYED MATERIALS BETWEEN THE LAPPED SHEETS. NEVER SPRAY INTO OPEN EDGE OF SEAM.

SEAMS MAY RUN EITHER HORIZONTAL OR VERTICAL. WHEN RUNNING HORIZONTAL, THE OPEN EDGE OF THE 4" SEAMS SHALL BE AIMING UP OR SHINGLED AS SHOWN.

STAPLE SEAMS ONLY THROUGH THE HDPE AREA AS SHOWN AND OVERLAP ALL SEAMS 4" AND APPLY PARA JT TAPE. INSTALL PARASTICK N DRY OVER SEAM EDGES WITH PARAPRIMER.

IN ORDER TO PREVENT DAMAGE TO THE MEMBRANE USE CONCRETE DEBIES OR PLASTIC SAND CHAIRS BETWEEN THE REBAR AND THE PARASEAL GM/LG TO HOLD THE PARASEAL GM/LG TIGHT AGAINST THE LAGGING.

NOTES: PARASEAL PRODUCTS REQUIRE A MIN 24 PSF OF COMPACTION/CONFINEMENT IN ORDER TO FUNCTION AS DESIGNED.

The architecture, engineering, and design of the project using the Tremco products are the responsibility of the project's design professional. All products and systems must comply with local building codes and standards. This detail is for general information and guidance only and Tremco specifically disclaims any liability for the use of this detail. The project design professional determines, in its sole discretion, whether this detail or a functionally equivalent detail is best suited for the project. This detail is subject to change without notice. Contact Tremco to ensure you have the most recent version.

Paraseal GM/LG 20 Mil Blindside Walls



Tremco Technical Support: 866-209-2404

Detail: Paraseal GM/LG 20 Mil Seam at Blindside Wall

Drawn by: KAB

Checked by: WH

Scale: NTS

Date: 3/29/2022

File Name:

BSW-GM20-S-01



Construction Products Group

www.tremcocpg.com