



WHEN SPRAYING SHOTCRETE OR OTHER MATERIALS AGAINST PARASEAL LG, SPRAY EITHER DIRECTLY AT THE SEAM OR AT THE CLOSED EDGE OF THE SEAM SO AS NOT TO LODGE SPRAYED MATERIALS BETWEEN THE LAPPED SHEETS. NEVER SPRAY INTO OPEN EDGE OF SEAM.

SEAMS MAY RUN EITHER HORIZONTAL OR VERTICAL. WHEN RUNNING HORIZONTAL, THE OPEN EDGE OF THE 4" SEAMS SHALL BE AIMING UP OR SHINGLED AS SHOWN.

SEAMS OVERLAPPED 4" MIN. AND SECURED WITH WIDE CROWN BOX STAPLES EVERY 3" O.C. AND WITH NAILS AND WASHERS EVERY 24" O.C. IN ORDER TO PREVENT DAMAGE TO THE MEMBRANE USE CONCRETE DEBIES OR PLASTIC SAND CHAIRS BETWEEN THE REBAR AND THE PARASEAL LG TO HOLD THE PARASEAL LG TIGHT AGAINST THE LAGGING.

NOTES: PARASEAL PRODUCTS REQUIRE A MIN 24 PSF OF COMPACTION/CONFINEMENT IN ORDER TO FUNCTION AS DESIGNED.  
 NOT RECOMMENDED FOR USE IN SUBMERGED CONDITIONS.

The architecture, engineering, and design of the project using the Tremco products are the responsibility of the project's design professional. All products and systems must comply with local building codes and standards. This detail is for general information and guidance only and Tremco specifically disclaims any liability for the use of this detail. The project design professional determines, in its sole discretion, whether this detail or a functionally equivalent detail is best suited for the project. This detail is subject to change without notice. Contact Tremco to ensure you have the most recent version.

**TREMproof TWS Blindsided Wall**



Detail: TREMproof TWS at Blindsided Wall - Typical Seam				File Name:
Drawn by: HDE	Checked by: WH	Scale: NTS	Date: 4/22/2022	TWS-BSW-03
<a href="http://www.tremcocpg.com">www.tremcocpg.com</a>				

