



TREMproof 260 at 100 wet mils

Wood lagging

TREMDrain 1000 as specified

Secure Paraseal LG using wide crown box staples at 6" O.C. minimum.

Grind inside face of beam and web using wire wheel or wire brush so that the metal is "bright" then apply Paraprimer over beam.

6" Parastick N Dry adhered with Paraprimer

NOTE: Paraseal products require a min of 24 PSF of compaction/confinement in order to function as designed.

TREMCO

www.tremcosealants.com

3735 Green Road * Beachwood, OH 44122
 Phone : 866-209-2404 * Fax: 216-766-5535

Detail: TREMproof TWS AT BACKLAGGED SOLDIER PILE - PLAN VIEW

This detail is intended for conceptual purposes only.

Drawn by: MI

Checked by: AC

Scale: None

Sheet Number:

Date: 5/27/2016

File Name:

TWS-BSW-07

Rev #

00